

29 Mhz Channel Numbers and their respective Frequencies

10	29.725
12	29.745
14	29.765
16	29.785
18	29.805
20	29.825
22	29.845
24	29.865
26	29.885
28	29.905
30	29.925
32	29.945
34	29.965
36	29.985

40 Mhz

<i>50</i>	<i>40.665</i>
<i>53</i>	<i>40.695</i>